

Mono Earpiece Headset

Dual Earpiece Headset



ClearOne


CHAT® | USB Headsets

CHAT 10D, CHAT 20M/20D, CHAT 30M/30D


Quick Start Guide

Connect Headset

Connect to USB port on computer.



Headset Controls



- Call Answer/Hang up
- Headset Volume Up/Down
- Microphone Mute/Unmute
- Status LED
 - Blue - Connected and Unmuted
 - Red - Connected and Muted

Adjust Headset

Slide headband in/out of earpieces to adjust.



2 cm
3/4"

Position microphone close to mouth by rotating or bending.

Rotate microphone to use on either side of face.

NOTE: This device is automatically recognized by your system as a conferencing device and is Plug-and-Play with your conferencing software. Use with other programs must be configured in your system.

ClearOne Headquarters:

5225 Wiley Post Way
Suite 500
Salt Lake City, UT 84116

Tel: 801.975.7200
Toll Free: 800.945.7730
Fax: 801.977.0087
E-mail: sales@clearone.com

ClearOne Technical Support:

Tel: 800.283.5936
E-mail: tech.support@clearone.com