ClearOne.

APPLICATION NOTE

CONVERGE® Pro

PRODUCTS SUPPORTED:

CONVERGE Pro models: 880, 880T, 880TA, 840T, 8i, TH20, VH20, SR1212, SR1212A

CLEARONE DOCUMENT 801-000-013 (REVISION 1.1) August, 2013 CONNECTING TANDBERG® C-SERIES TO A CLEARONE CONVERGE PRO

OVERVIEW

The purpose of this document is to provide a set of instructions on connecting a Tandberg C-Series codec to the ClearOne CONVERGE Pro device. The codec has two types of audio inputs: balanced XLR and unbalanced RCA. This document will describe both methods.

This document applies to all versions of the CONVERGE Pro family of products.

NOTE: This document was written using a ClearOne Converge Pro 880TA, firmware version 3.0.6.0, and a Tandberg C60 codec, firmware version TC3.0.0.211036.

CONNECTION REQUIREMENTS

The following requirements must be met before proceeding:

- Familiarity with configuring a CONVERGE Pro system using the Tandberg Audio Console application
- An understanding of configuring the gains on a CONVERGE Pro system. A review sheet Application Note is available at: http://www.clearone.com/uploads/resource/801_151_801_06_Optimizing_Gain_Structure_Rev1_0-1.pdf
- The Tandberg Audio Console is installed on the computer being used for this configuration procedure. The console is available for download at:

http://developer.cisco.com/web/telepresence-developer/tools/integrators/tc-console

• An IP connection is established between the Tandberg codec and the computer being used for this configuration

NOTE: Configuration of the CONVERGE Pro is too extensive to cover in this document. It is assumed that the reader is familiar with the set up and configuration of the ClearOne CONVERGE Pro.

CONNECTING THE CONVERGE PRO

Once the routing and the gain structure are set in the CONVERGE Pro, the system is now ready to connect the CONVERGE Pro to the Tandberg codec.

If connecting to the balanced XLR connector of the Tandberg codec, it will be necessary to make a male XLR to Mini-Phoenix-type connector audio cable (See Figure 1).



Figure 1.

If the unbalanced RCA-type connector Line Input of the Tandberg codec is to be connected, it will be necessary to make an RCA to Mini-Phoenix-type connector (See Figure 2).



Figure 2.

Connect the Mini-Phoenix-type connector to the output of the CONVERGE Pro where you have routed your microphones for video conferencing. Connect either the XLR-type connector to the microphone input of the Tandberg codec or the RCA-type connector to the Line input of the Tandberg codec. In this document, Microphone Input 1 and Line Input 1 of the Tandberg codec are being used.

It will also be necessary to make a cable to connect the Line Output of the Tandberg codec to the Line Input of the CONVERGE Pro (See Figure 3). Line Output 1 of the Tandberg was used for this document.

The jumper cable is ties the negative and ground connections of the Line Input together to reduce any noise that may be introduced from the cabling.



Figure 3.

CONNECTION REQUIREMENTS

Connect to the codec with the Tandberg Audio Console software.

Once you are connected, turn off all processing on the inputs and outputs of the codec.

Microphone Input Connection

If you are using the Microphone (XLR) input, you must click on the carrot (>) next to Settings and Microphone 1 to expand the Microphone Input configuration menu (See Figure 4).

Set all Settings and Microphone configurations exactly as shown in Figure 4.

	× Microphone	C
 Microphone Input Settings Mixer Mode: Fixed Mute: Off AGC: Off Channels: 1 	✓ Settings Mixer Mode Mixer Mode Mute Off AGC Channels 1	
	✓ Microphone 1 Mode On Level (dB) 0 Type Line Echo Control Off Noise Reduction Off Equalizer Ø	 Microphone 1 Settings Mode: On Level (dB): 0 Type: Line Echo Control: Off Noise Reduction: Off Equalizer: Off



Line Input Connection

If using the Line Input, click on the carrot (▶) next to Settings and Line 1 to expand the Line Input configuration menu. Set all Settings and Line 1 configurations exactly as shown in Figure 5.

	× Line Input		
 Line Input Settings Mixer Mode: Fixed Mute: Off AGC: Off Channels: 1 	 ✓ Settings Mixer Mode Mute AGC Channels ✓ Line 1 Mode Level (dB) Channel Equalizer 	Fixed ▼ Off ▼ Off ▼ 1 ▼ X On ▼ 0 ▼ Mono ▼ Off ▼	Line 1 Settings Mode: On Level (dB): 0 Channel: Mono Equalizer: Off



Loudspeaker and Line Input Connection

To access the Loudspeaker and Line 1 configuration menu, click on the carrot (\blacktriangleright) next to Settings and Line 1. Set all Loudspeaker and Line 1 setting as shown in Figure 6.

	Loudspeaker	×	
Loudspeaker Settings • Loudspeakers: Off • Channels: 1	 ✓ Settings Loudspeaker Channels 	Off ▼ 1 ▼	
	✓ Line 1 Mode Level (dB) Channel Type Equalizer	X On ▼ 0 ▼ Mono ▼ Auto ▼ Øff ▼	Line 1 Settings Mode: On Level (dB): 0 Channel: Mono Type: Auto Equalizer: Off

Figure 6.

Once all of this processing has been turned off, place a video call and fine-tune the gain settings of the CONVERGE Pro inputs and outputs.

Refer to the following application note:

http://www.clearone.com/uploads/resource/801_151_801_06_Optimizing_Gain_Structure_Rev1_0-1.pdf

When the video connection has been established, you will notice two more connections show up in your Tandberg Audio Console. These are virtual connections depicting the input from the far end and the output feeding the far end.

There is only one setting to verify and that is the AGC on the Remote Input. Set this to Off as displayed in Figure 7.

Remote Input 12		•
✓ Settings		
AGC	Off	▼
C1 TEST		



If you have any questions or need assistance with this application please contact ClearOne Technical Support at 1-800-283-5936 or tech.support@ClearOne.com.

HEADQUARTERS:

Salt Lake City, UT USA 5225 Wiley Post Way Suite 500 Salt Lake City, UT 84116

Tel: 801.975.7200 Toll Free: 800.945.7730 Fax: 801.977.0087 E-mail: sales@clearone.com EMEA Tel: +44 (0) 1189.036.053 E-mail: global@clearone.com

APAC Tel: +011.852.3590.4526 E-mail: global@clearone.com LATAM Tel: 801.974.3621 E-mail: global@clearone.com TechSales Tel: 800.705.2103 E-mail: techsales@clearone.com

Technical Support Tel: 800.283.5936 E-mail: tech.support@clearone.com

© 2013 ClearOne Inc. All rights reserved. Information in this document is subject to change without notice. 801-000-013 Rev. 1.1 - August 2013.