User Manual



BMA 360D



ClearOne Contacts

Headquarters

5225 Wiley Post Way Suite 500 Salt Lake City, UT 84116

Sales

Tel: +1.801.975.7200 sales@clearone.com

Notices

© 2025 ClearOne, Inc. All rights reserved. Information in this document is subject to change without notice. Document: DOC-0578-001v1.1 January 2025

Important Safety Instructions

- 1. Read and follow all instructions.
- 2. Keep these instructions.
- 3. Do not use these devices near water.
- 4. Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with manufacturer instructions. 5.

Headquarters

Tel: +1.801.975-7200

Technical Support

Tel: +1.801.974.3760

audiotechsupport@clearone.com

- 6. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has 7. two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 8. Protect the PoE injector's power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 9. Only use attachments/accessories specified by the manufacturer.
- 10. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 11. Unplug this apparatus during lightning storms or when unused for long periods of time.
- 12. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- 13. Disconnect the apparatus from the AC mains with the mains plug. This plug shall remain readily operable.
- 14. Never push objects of any kind into this product through cabinet slots as they may touch dangerous voltage points or short out parts that could result in fire or electric shock.
- 15. This product can interfere with electrical equipment such as tape recorders, TV sets, radios, computers and microwave ovens if placed in close proximity.
- 16. Class 2 Wiring IS REQUIRED. Only qualified personnel should wire and install.
- 17. Underwriters Laboratories (UL) requires these safety notifications

Contents

No	otice	èsi
1.	Intr	roduction1
	٠	The BMA 360D features the following1
	٠	Applications1
2.	Phy	ysical Installation2
	•	Connect Speakers2
	٠	Important: Please note the following PoE requirements2
	٠	Install the BMA 360D with Seismic Cables2
	٠	Install the BMA 360D with Pole Mount3
	٠	Connect the BMA 360D to Your Network4
	٠	Network Configuration4
3.	Pol	E Requirements4
4.	Dis	scovery5
5.	Dai	nte Configuration7
6.	Dai	nte Audio Routing8
7.	Co	nfiguration and Tuning Controls12
	٠	Speaker Bridge Mode and LED Settings12
	٠	SmartMix BMA Gain Setting13
	٠	SmartMix AEC and NLP13
	٠	SmartMix Noise Cancellation14
	٠	SmartMix Microphone and Speaker Filters16
	•	Filter Type Description16
	٠	SmartMix Automatic Level Control (ALC)17
ii	٠	SmartMix AEC Reference17

1. Introduction

The BMA 360D features the following:

- Deep Sidelobe Beamforming, DsBeam[™], provides unparalleled sidelobe depth, below -40 dB, resulting in superior rejection of reverb and noise in difficult spaces for superb clarity and intelligibility.
- Precision beamforming to easily achieve distortion-free, full 360-degree coverage of any room shape and any seating arrangement using ClearOne Audio Intelligence[™].
- 6G Acoustic Echo Cancellation (AEC) delivers unparalleled per-beam full-duplex audio performance. On-board audio algorithms, like noise reduction, filtering, and Automatic Level Control, can eliminate the need for per-beam processing in a DSP mixer – or greatly reduce DSP mixer resource requirements.
- Built-in, robust power amplifiers, configurable as 4 x 15 Watt or 2 x 30 Watt, provide flexibility for driving loudspeakers.
- ClearOne's breakthrough technologies, FiBeam, DsBeam, and 6G AEC combine to create VividVoice[™], a significant advancement for professional conferencing.
- A Dante interface provides 12 unprocessed beam outputs for maximum flexibility when connecting to a multi-channel DSP, one SmartMix output provides automixing, AEC, and noise cancellation processing in a single output, four input channels feed the 4 speaker channels, and one input channel delivers the AEC reference.
- Integrated features significantly reduce system design complexity, simplify installation, consume less rack space, and lower system cost.
- Single workflow for configuration using CONSOLE® AI LITE software.
- Supports two different ceiling grid types: 24 IN and 600mm. It incorporates a VESA-mount hole pattern that supports pole mounting. Hard-ceiling mount adapter kits are also available.

Applications

- Audio conferencing
- Video conferencing Workspaces
- Conference rooms
- Boardrooms
- Courtrooms
- Classrooms
- Telemedicine theaters


2. Physical Installation:

Unpack the BMA 360D and Inspect it carefully. If the shipment shows obvious signs of damage, retain the original box and packing material for inspection by the carrier. Contact the carrier immediately. ClearOne is not responsible for product damage incurred during shipment.

Connect Speakers

A good time to connect external speakers is before you install the BMA 360D in the ceiling. With speaker wire (not included), connect external speakers to the Phoenix Euroblock connectors.

The BMA 360D can be operated as 4 independent 15 Watt amplified channels, or in Bridged mode for 2 channel x 30 Watt configuration.




Important: Please note the following PoE requirements:

- When not utilizing the BMA 360D amplifiers, a 36 Watt PoE+ supply may be used.
- When using the BMA 360D amplifiers, a 90 Watt PoE++ supply must be used.
- ClearOne recommends the following PoE power supply kits:
 - * ClearOne 36 Watt supply PN# 910-3200-202
 - * ClearOne 90 Watt supply PN# 910-3200-209

Install the BMA 360D with Seismic Cables

You can mount the BMA 360D in a suspended ceiling, held in place by the standard T-bar grid, with additional 1/8" diameter seismic cables (not included). For safety, ClearOne recommends attachment at the four points shown.



Install the BMA 360D with Pole Mount

The BMA 360D can be suspended from the ceiling using a horizontal VESA pole mount, commonly referred to as a projector ceiling mount. The BMA 360D back panel features a standard 100 x 100 mm VESA hole pattern with M4 screw holes. For proper installation, refer to the detailed instructions provided with your pole mount.


Note:

- 1. BMA microphone weight: 11.1 lbs (5 kg)
- 2. M4 screw (Maximum Length): M4 x 10 mm



Connect the BMA 360D to Your Network

Connect the BMA 360D to your Dante enabled network and PoE power supply. It is recommended to use ClearOne certified PoE injectors in-line with your BMA 360D.



Network Configuration

The BMA 360D has a single Network connection which serves both IP Configuration and Dante audio connection roles. To perform initial configuration, connect both the BMA 360D and your PC to a DHCP enabled network. You may then discover and configure the BMA 360D using ClearOne's CONSOLE AI Lite Software. Configuration and control of the BMA 360D is achieved through ClearOne's CONSOLE AI Lite software.

Please visit us at <u>https://www.clearone.com/console-ai-lite-configuration-software-0</u> for CONSOLE AI Lite downloads and details.

3. PoE Requirements:

Power delivery to the BMA 360D is exclusively via PoE injection. If speakers are not connected to the BMA 360D, a 36 Watt PoE+ supply (PoE 802.3AF) can be used. When one or more speakers are connected to the BMA 360D, a PoE++ (802.3bt) 90 Watt injector must be used. Note that the detected available PoE power is denoted in CONSOLE AI Lite in the Admin section. If a 90 Watt supply is detected, the PoE Status will be denoted as "PoE++"

ONSOLE® AI Lite			-	\times
Admin 🗲 - 🔇	🖄 🚫 🗅	ne 📮 📑		?
Device Information		Firmware		
BMA 360D		Select Firmware File		
Firmware:	1.0.3.13	✓ Only show latest firmware for each device		
Serial Numper:	5699-2327-40			 -
IP Address:	10.101.24.85	File Name Type Version Description		1
MAC Address	00:90:79:10:8A:27	BMA_360D-v1.0.3.11.mdo BMA 360D 1.0.3.11 Send Additional Information		
Dante IP Address:	10.101.24.82			
Dante MAC Advess:	00:1D:C1:28:F9:DC			
PoE Status:	PoE+			

4. Discovery:

CONSOLE AI Lite will discover all ClearOne equipment on the network that can be controlled via CONSOLE AI Lite. These available devices will be displayed in the Discovered Devices panel:

Discovered Devices
Manually Discover IP Address: Add
Image: Second system Image: Second system Image: Second
Connect

If multiple BMA 360Ds are present on the network, you can identify each by clicking on the Locate lightbulb icon. This will cause the corresponding physical BMA 360D's LED bar to flash green until the Locate icon is clicked again, or the Locate Timeout period has expired.



Once connected, navigate to the Device Settings window to perform any modification, or confirm your network settings:

Online 🕄 🔒				
I0 Select Firmware Select Firmware File Nam BMA_360D-v1.0.	Erie Devices BMA360D-28f9at 5699-2327-40 BMA 360D	Device Settings Device Settings Device Settings Device Type: Device Name: Serial Number: Locate Timeout (minut Ethernet Port ① Use DHCP ① Use Static IP: IP Address: Subnet Mask: Gateway: DNS Address 1: DNS Address 2:	□ × ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■	×
			Close	

5. Dante Configuration:

The Dante IP address and Dante MAC address can be found in CONSOLE AI Lite under the Admin>Device Information panel.

Device Information	
BMA 360D	
Firmware:	
Serial Number:	5699-2327-40
IP Address:	10.101.24.85
MAC Address:	00:90:79:10:8A:27
Dante IP Address:	10.101.24.82
Dante MAC Address:	00:1D:C1:28:F9:DC
PoE Status:	PoE+


Audio routing to and from the BMA 360D is done via Dante Controller. Be sure that you have the BMA 360D and at least one other Dante enabled device, such as a DSP or Dante Virtual Soundcard attached to your Dante network prior to beginning configuration and routing. Use the Dante Controller software on your computer to verify that your BMA 360D appears on the Dante network's device list with the Device Name assigned in the Device Settings panel.

🥝 Dante Controller - Network View								
File Devices View	Help							
🗉 🔗 🖿 🚖	🗉 🗲 🛋 🔤 🕀 🔕							
Routing Device Info	Clock Status Network Sta	tus Events						
Device Name	Model Name	Product Version	Dante Version					
BMA360D-28f9dc	BMA 360D	1.0.1	4.2.3.8					
BMA_360D	BMA 360D	1.0.1	4.2.3.8					
CONNECT-049a26	CONNECT One	1.0.2	3.7.0.24					
CPRO2-0e86e6	CONVERGE PRO 2	1.0.3	3.8.2.1					
CPRO2-0e8a44	CONVERGE PRO 2	1.0.3	3.8.2.1					

Your BMA 360D is now successfully connected to the Dante network and you can now route audio between your device and other Dante-enabled devices on the same network efficiently and with high audio quality.


6. Dante Audio Routing:


The BMA 360D Dante input and output channel options are designed to meet a variety of conference and voice lift needs. The graphic below outlines audio connection options for both microphone audio to the Dante network, as well as audio from the Dante network delivered to the BMA 360D's built in 4 channel amplifier.




Use the Dante Controller software to configure audio routing between your device and other Dante-enabled devices on the network. This software is available from the Audinate webpage: <u>www.audinate.com/products/software/</u> <u>dante-controller</u>


For detailed audio control and/or voice lift enabled designs, independent feeds from each individual beam are available via Dante output channels 1-12 from the BMA 360D. These output channels have no gain, mute or volume control processing and are ideal for interfacing the BMA 360D with a Dante enabled audio processor.





For simple room designs, utilize the SmartMix output 13 with integrated AEC, noise cancellation, filtering and zone mixing features. Utilizing the SmartMix microphone output and the built in amplifier channels, a complete system for cloud conferencing can easily be achieved. Below is a routing example using the Dante Virtual Soundcards (DVS) software on a PC for cloud conferencing. This example also utilizes the BMA 360D 4 channel amplifier for in room audio.





Note: That when using the SmartMix output, the AEC reference connection must also be used for proper Acoustic Echo Cancellation performance.

🧕 Dante Controller - Network View																										
File Devices View Help																										
	8)	ł	Ì															I	Prir	na	ry L	.ea	der	Clock: (¢
Routing Device Info Clock Status Network	< Stat	tus	1	Eve	ent	s																				
Filter Transmitters Filter Receivers	+ Transmitters (11)	BMA360D-28f9dc	i	Beam 2			Deam +	Beam 6	Beam 7	Beam	Beam 9	Beam 10 D	Beam 11	Beam 12 D	SmartMix D	BMA_360D +	CONNECT-049a26 +	CPR02-0e86e6 +	CPR02-0e8a44 +	CPR02-0e8a78 +	CPR02-0f7d84 +	-	/S	L8111	ກົດດ ສິຮິຮິ utput C	
																									(
BMA_360D		Ε]													+	+	+	+	+	+	+	+			Ĩ.
- O Speaker_01	0																								9	
 ∩ Speaker_02 ∩ Speaker_03 ∩ Speaker_04 Choo AECReference_01 Reference 	0000																							_		
+ CONNECT-049a26 Audio	-	Ŧ	1													+	+	$\left +\right $	+	+	+	+	+	Ŧ	-	Î.
+ CPR02-0e86e6		Ŧ														+		Ŧ			+			+		
+ CPR02-0e8a44		Ŧ														Ŧ	Ŧ	Ŧ	Ŧ	=	+		_	Ŧ		
+ CPR02-0e8a78		Ŧ														Ŧ	Ē	Ē	Ŧ	Ŧ	Ŧ	_	_	Ŧ		
+ CPR02-0f7d84		Ŧ														Ŧ	Ŧ	Ð	Ŧ	Ŧ	Ð		_	Ŧ		
+ CPR02-11aae6		F														Ŧ	Ð	Ð	Ð	_	Ð		_	Ŧ		
FEED4		E														Ŧ	H	H	Ŧ		Ŧ			Ŧ		
- L8111-Ryan	<u> </u>	Ē														Ŧ				Ŧ	Ŧ			Ξ		ł
- O 01 - O 02 - O 03	0														0											

7. Configuration and Tuning controls in CONSOLE AI Lite

Speaker Bridge Mode and LED Settings


Config - Beamformer_01				×
General Advanced				
a. Speaker Bridge Mode:	🔘 Not Brid	ged (4x 15 watts) (Bridged (2x 30 watts)	
	■1 2 ■ + - 0 0 0	■ ■ 3 4 ■ + - ■ 0 00000		
h	annel Speaker_02 and cha	innel Speaker_04 when ii	n bridged mode.	
LED Settings —				
Mute Brightness	High 👻	Unmute Brightness	High 👻	
Mute Blink Mode	On-Steady 🔻	Unmute Blink Mode	e On-Steady 🔻	
Mute Color	Red 🔻	Unmute Color	Blue 👻	
L]
		Close		

- a. Speaker Bridge Mode allows the selection of either fully individuated 4 x 15 Watt Amplifier operation or 2 x 30 Watt Bridged mode operation.
- b. LED Settings allow for customization of LED color, blink and brightness when in Muted or Unmuted states.

SmartMix BMA Gain Setting

You can set the gain level in 3 ways:


- Drag the slider (a).
- Type a value in the text box (b).
- Tap or click the incrementer and decrementer buttons beside the text box (b) to adjust the value.



Note: Gain controls, Mute and Filtering options only apply to the SmartMix Dante Channel 13 output and do not affect the individuated Dante Beam output Channels 1-12.

SmartMix AEC and NLP

AEC (Acoustic Echo Cancellation) reduces or removes acoustical echo from an input signal to improve audio clarity.



The AEC function provides full bandwidth (20Hz to 22kHz) echo filtering of the microphone signal. It uses a reference source (Dante input 5) which should include a mix of all far end participant receive audio that is being delivered to the room speakers.

Non-linear Processing (NLP) increases the power of echo cancellation for challenging acoustical environments.

You can select the following:

- Whether or not you want to use AEC. Tap or click the checkbox (a) if you want to use AEC.
- The level of aggressiveness. Tap or click the appropriate radio button (b).

Note: AEC processing is only available for the SmartMix Dante output channel 13 from the BMA 360D.

AEC - Beamformer_01	×
a. V Enable Acoustic Echo Canceller	
 Non-linear Processing (NLP) Aggressive Medium Soft Off 	
Close	

SmartMix Noise Cancellation




Noise Cancellation removes ambient (background) noise from an input signal, with no noticeable degradation in signal quality. To enable noise cancellation, tap or click the Enable Noise Canceller check box. You can change the cancellation depth with any of the following methods:

- Drag the slider (a).
- Type a value in the text box (b).
- Tap or click the incrementer and decrementer buttons beside the text box to set the value (c).

Note: Noise Cancellation processing is only available for the SmartMix Dante output channel 13 from the BMA 360D.

🕘 Noise Canceller - SmartMix 🛛 🗙
Enable Noise Canceller
Cancellation Depth
\ominus b .12 \oplus c .
Close

SmartMix Microphone and Speaker Filters




Filters enable you to shape the audio signals from microphone inputs channels and to speaker output channels for improved audio quality. You can add up to four filters to a microphone or speaker channel. Available filter types include the following:

Filter Type Description

- All Pass Frequency range is 20Hz to 20kHz. All pass changes the phase of the audio signal at the set frequency.
- High Pass Selectable frequency cutoff is 20Hz to 20kHz. Rolloff is 12dB/octave. Level is fixed at 0dB.
- Low Pass Selectable frequency cutoff is 20Hz to 20kHz. Rolloff is 12dB/octave. Level is fixed at 0dB.
- Notch Center frequency range is 20Hz to 20kHz. Bandwidth is from 0.05 to 5.00 octaves in 0.01 octave increments. Level is fixed at -80dB.
- Parametric Equalizer (PEQ) Center frequency range is 20Hz to 20kHz in 0.01Hz increments. Bandwidth is 0.05 to 5 octaves in 0.01 octave increments. Level range is -15 to +15dB in 0.5dB increments.

④ Filters - SmartMix



Graph Phase



SmartMix Automatic Level Control (ALC)



ALC utilizes a level normalization algorithm to keep soft and loud local participants at a consistent level.

SmartMix AEC Reference

The BMA 360D Dante input Channel 5 delivers far-end receive audio to the built-in Acoustic Echo Canceller (AEC) so that echo can be removed from the microphone audio.

The Linked Channel drop down allows for the AEC Reference levels, filtering and Mute status to follow one of the Amplifier channels. When linked, the volume slider (b) will be disabled.

- The volume slider (b) allows for control of the AEC reference gain.
- Metered dB level of the AEC Reference signal (c) Post Gain.

